



Specifications:

	SL-10L-12V	SL-10L-24V	SS-20L-12V	SS-20L-24V
System Voltage	12 V	24 V	12 V	24 V
Maximum Voltage	30 V	50 V	30 V	50 V
Rated Solar Input	10 A		20 A	
Rated Load	10 A		20 A	
25% Current Overload	5 minutes	N/A	5 minutes	N/A
Regulation Voltage: Sealed PWM	14.1	28.2	14.1	28.2
Regulation Voltage: Flooded PWM	14.4	28.8	14.4	28.8
Temperature Compensation	-27 mV/°C	-54 mV/°C	-27 mV/°C	-54 mV/°C
Low-Voltage Disconnect (LVD)	11.7 V	23.4 V	11.7 V	23.4 V
Low-Voltage Reconnect (LVR)	12.8 V	25.6 V	12.8 V	25.6 V
Self-consumption	8 mA	9 mA	8 mA	9 mA
Ambient Temperature Range	-40 to 60°C			

Battery Type Selection:



For Sealed Batteries:
Battery Select Jumper **INSERTED**




For Flooded Batteries:
Battery Select Jumper **REMOVED**




IMPORTANT:
The SunLight charging algorithm is compatible with lead-acid or NiCd batteries. *NiMH, Li-ion, and other battery chemistries are not compatible with the SunLight charging algorithm.*

Lighting Control Options:



Turn the dial to the desired setting. This illustration shows the dial set to **OFF**.



See the SunLight Operator’s Manual for detailed information on lighting control settings.

Contact Information:
Technical Support: morningstarcorp.com/support
Phone: 1-215-321-4457



SOLAR LIGHTING CONTROLLER

Quick Start Guide



SunLight-10
Solar Lighting Controller

SunLight Models:	
SL-10L-12V	SL-10L-24V
SL-20L-12V	SL-20L-24V



SunLight-20
Solar Lighting Controller

In the Box:



SunLight-10
Solar Lighting Controller

OR



SunLight-20
Solar Lighting Controller

Tools Required:

- 3/16" (5 mm) Flathead Screwdriver
- #2 Phillips Screwdriver
- Multimeter



Warranty Registration:
<https://www.morningstarcorp.com/product-registration/>

Scan QR Code to go directly to the SunLight Operator’s Manual and warranty information online.



Important Safety Information:




WARNING: Shock Hazard
The SunLight solar lighting controller must be installed by a **qualified** technician in accordance with the electrical regulations of the country of installation.



IMPORTANT: READ the SunLight Operator’s Manual for safety and regulatory information, instructions on configuration and operation, and warranty information.


Recommended Minimum Clearance:



- WARNING: Explosion Hazard**
Never install the SunLight in an enclosure with vented/flooded batteries. Battery fumes are flammable and will corrode and destroy the SunLight circuits. Ensure sufficient ventilation.
- CAUTION: Equipment Damage**
Do not expose the SunLight CC to weather. Locate in a dry, protected area to prevent equipment damage. Ensure the minimum clearance requirements are followed to provide adequate ventilation and prevent the unit from overheating.

Mounting:

- Step 1: Choose Mounting Location**
Locate the SunLight on a **vertical** surface within 10 feet (3 m) of the battery bank that is protected from direct sun, high temperatures, and water.
- Step 2: Check for Clearance and Ventilation**
Place the SunLight in the location where it will be mounted. Verify that there is sufficient room to run wires and that there is ample room above and below the controller for air flow.
- Step 3: Mount the Controller**
Mark and drill holes as needed, or use self-tapping screws, and secure the controller in place.




Photovoltaic (PV) Array


See the Morningstar PV String Calculator at: <http://string-calculator.morningstarcorp.com/>

30 Voc Max @ 12 V battery /
50 Voc @ 24 V battery

12 Vdc Module 12 Vdc Module



- IMPORTANT:** Array voltage should **NEVER** exceed the maximum input voltage.
- WARNING: Shock Hazard**
The solar PV array can produce open-circuit voltages in excess of 40 Vdc when in sunlight. Verify that the solar input breaker or disconnect has been opened (disconnected) before installing the system wires.



LEGEND

	Negative (-)
	Positive (+)
	Ground

NOTE: Fork-terminal connectors are not required. Use only copper wire with minimum 75°C insulation rating and between 10 AWG (5.2 mm²) and 14 AWG (2.1 mm²) gage.

Recommended Order of Installation	WIRING AND TORQUE REQUIREMENTS						
	Component	Wire Size (Solid)	Wire Size (multistrand)	Wire Size (fine strand)	Torque (Maximum)	Tool Required	
	1 2	Battery Terminals	#10 AWG 5.2 mm ² (Maximum)	#10 AWG 5.2 mm ² (Maximum)	#10 AWG 5.2 mm ² (Maximum)	10.6 in-lbs. (1.2 Nm)	3/16" (5 mm) Flathead or #2 Phillips Screwdriver
	3 4	Solar Terminals					
5 6	Load Terminals						
Fuses, Breakers, or Disconnects		*The sizing of fuses, breakers, or disconnects must be based on required wire ampacity. Do NOT close breakers or disconnects, or insert fuses in the fuse-holder, until after all wiring has been completed.					

IMPORTANT: Example only. Actual wiring may vary. **READ** the SunLight Operator's Manual for mandatory safety requirements. All configurations must comply with local and national electric codes. Consult your local electric authority to ensure compliance.

For additional information about the LED indications or the TEST Button functions, see the SunLight Operator's Manual.

WARNING: Risk of Fire
All over-current protection devices and wiring must be sized properly.

WARNING: Shock Hazard
Test between all terminals and ground before touching. Power or accessory terminals are **NOT** electrically isolated from DC input and may be energized with hazardous solar voltage.

WARNING: Shock Hazard
Fuses, circuit breakers, and disconnect switches should never open grounded system conductors. Only GFDI devices are permitted to disconnect grounded conductors.

IMPORTANT: Ensure there is **only 1** DC Negative-to-Ground Bond in the entire system.

- Power UP Sequence:**
1. Connect Battery/Battery Bank.
 2. Connect Solar.
- Power DOWN Sequence:**
1. Disconnect Solar.
 2. Disconnect Battery/Battery Bank.